




3 PIECE DRILLING INSTRUCTIONS




DRILLING #1
Ball Choice: All top weights
Reaction: Delayed breakpoint, moderate backend on light to medium oil
Suitable for: Slower ball speeds, drier heads and pines, spare shooting
Flare potential: Low
CG Placement: 3/4 oz. positive side weight, 3/4 oz. finger weight
Balance Hole: None needed



DRILLING #2
Ball Choice: All top weights
Reaction: Medium length with strong backend on light to medium oil
Suitable for: Light to medium oil
Flare potential: Low
CG Placement: 3/8" from PAP on the grip midline
Balance Hole: Place balance hole 9 inches from the center of span and drill back to 1/2 oz. positive side weight. If stronger backend is needed, drill hole deeper to 1/2 oz. negative side weight.



DRILLING #3
Ball Choice: Top weights 2 1/2 oz. or lower
Reaction: Earlier breakpoint, smooth backend hook on light to medium oil
Suitable for: Low ball tracks, faster ball speeds
Flare potential: Low
CG Placement: 2 inches from PAP on the grip midline
Balance Hole: Place on PAP, drill back to 1/2 oz. negative side weight



DRILLING #4
Ball Choice: All top weights
Reaction: Delayed breakpoint, moderate backend hook
Suitable for: Full rollers
Flare potential: Low
CG Placement: 3/4 oz. positive side weight, 3/4 oz. thumb weight
Balance Hole: None needed



EBONITE

PO Box 746

Hopkinsville, KY 42240

800-626-8350 270-881-1200 fax 270-881-1201

Visit our web site at www.ebonite.com